




VIDEO TUTORIAL:




INSTALLATION VIDEO:




Set language / Sprache einstellen / Sélectionner la langue / Selezione lingua / Seleccionar idioma / Taalkeuze / Wybór języka

English → Deutsch




Set unit / Einheit festlegen / Définir l'unité / Impostazione unità / Determinar unidad / Eenheid vastleggen / Ustalenie jednostki

KMH → MPH




Set wheel size / Eingabe Radumfang / Réglage de la circonférence de la roue / Immissione circonferenza ruota / Introducción de las dimensiones de la rueda / Invoer wielomtrek / Zadání obvodu kola

2155 → 2136




Set clock / Uhrzeit einstellen / Régler l'heure / Impostazione orario / Ajustar hora / Kloktijd instellen / Ustawienie czasu

00:00 → 15:36




Set fuel I/100 km / Fuel I/100 km einstellen / Régler Fuel (I/100 km) / Regolare Fuel I/100 km / Ajustar Fuel I/100 km / Fuel I/100 km instellen / Ustawianie Fuel I/100 km

1,0 → 7,6




Set total distance / Gesamtstrecke einstellen / Régler la distance totale / Impostazione percorso totale / Ajustar tramos totales / Totale afstand instellen / Ustawienie całkowitej długości dystansu

0 → 2.325




Set total time / Gesamtzeit einstellen / Régler la durée totale / Impostazione tempo totale / Ajustar tiempo total / Totale tijd instellen / Ustawienie czasu całkowitego

0:00 → 105:40




Set total fuel / Total Fuel einstellen / Régler Total Fuel / Regolare Total Fuel / Ajustar Total Fuel / Total Fuel instellen / Ustawianie Total Fuel

0,0 → 120,3




Set contrast / Kontrast einstellen / Régler le contraste / Regolare il contrasto / Ajuste del contraste / Contrast instellen / Ustawienie kontrastu


2 → 3



Setting menu / Einstellungs Menü / Menu réglages / Menu impostazioni / Menú de ajuste / Instellingsmenu / Menu ustawień



Reset / Nullstellen / Réinitialiser / Azzeramento / Colocar en cero / Op nul instellen / Zerowanie



Trip Section Counter (TS) / Trip Section Counter (TS) / Compteur partiel (TS) / Trip Section Counter (TS) / Trip Section Counter (TS) / Trip Section Counter (TS) / Trip Section Counter (TS)

Start / Stop



1. INSTALLATION OF THE BRACKET

1.1 Stem or handlebar?

1.2 Change handlebar -> Stem

→ The mounting bracket included in the package is intended for handlebar mounting. For assembly on the stem release the 4 screws on the back, turn the plate by 90° and secure again.

1.3 Installation of the bracket

1.4

1.5 A

1.5 B

1.6 Installation of the computer on the mounting bracket

2. INSTALLATION OF THE WIRED SENSOR AND STANDARD MAGNET

2.1

2.2 Installation of the wired sensor

2.3 Installation of the standard magnet

2.4 Adjusting of standard magnet

3. INSTALLATION OF THE WIRELESS SPEED TRANSMITTER

3.1 BC 12.12 STS

3.2 Transmission range of STS speed transmitter

3.3 Installation of the power magnet

3.4 Adjusting of power magnet

4. BATTERY CHANGE

4.1 Change battery / Bike Computer

4.2 Change battery / Speed transmitter

5. WHEEL SIZE CHART

5.1 Wheel Size Chart

ETRTO		ETRTO	
16 x 1,75 x 2	16 x 1,75 x 2	kmh mph	kmh mph
47-305	16x1.90	1272	32-622
47-406	20x1.75	1590	35-622
37-540	24x1.75	1948	37-622
47-507	24x1.75	1900	37-622
37-584	26x1 3/8, 650 STD	2086	40-622
37-590	26x1 3/8, 650x35A	2100	42-622
40-559	26x1.50	2030	47-622
42-559	26x1.60	2025	50-622
47-559	26x1.75	2050	54-622
50-559	26x2.00	2075	57-622
54-559	26x2.10	2100	60-622
57-559	26x2.25	2120	650x23C
57-584	27 1/2 x 2.25	2128	700x18C
28-630	27 x 1 1/4	2174	20-622
32-630	27 x 1 1/4	2220	23-622
40-635	28 x 1 1/2	2265	25-622
			28-622
			700x28C

6. PACKAGING CONTENT