

# Universal Fast Setting Box

## INSTRUCTION MANUAL

TOPLINE 2012/2016  
SIGMA ORIGINALS  
VDO R-LINE



VIDEOS &  
FURTHER  
INFORMATION

[goto.sigmasport.com/  
ufsb/service](http://goto.sigmasport.com/ufsb/service)

## FIRST START

**DE**

- Öffnen Sie das Batteriefach.
- Schließen Sie die Batterie an.
- Die **UFSB** ist jetzt betriebsbereit.

**EN**

- Open the battery compartment.
- Connect the battery.
- The **UFSB** is now ready for use.

**FR**

- Ouvrez le compartiment à piles.
- Raccordez la batterie.
- La **UFSB** est alors prête à fonctionner.

**PT**

- Abra o compartimento da pilha.
- Insira a pilha.
- A **UFSB** está agora operacional.

**NL**


- Open het batterijcompartiment.
- Sluit de batterij aan.
- De **UFSB** is nu klaar voor gebruik.

**IT**

- Aprire il vano batteria.
- Collegare la batteria.
- Il **UFSB** ora può essere messo in funzione.

**ES**

- Abra el compartimento de la pila.
- Coloque la pila.
- La **UFSB** ya está lista para funcionar.




**DE 1.0**

Schalten Sie die **UFSB** mit der **grünen** Taste ein.



Sie sehen:



Machen Sie zuerst die Basis-Einstellungen der **UFSB** (Start Settings).  
Mit der F3-Taste gehen Sie zu General Set.

Bestätigen Sie die Auswahl mit der F2-Taste und fahren mit den Einstellungen fort

**Diese Einstellungen machen Sie nur einmal bei der ersten Inbetriebnahme der UFSB.**

**1.1**

**Sprache Einstellen:**


- Wählen Sie mit den (▲) / (▼)-Tasten Ihre Sprache
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.2**

**Legen Sie nun das Datumsformat fest:**

- Auswahl mit den (▲) / (▼)-Tasten
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.3**

**Stellen Sie das Datum ein:**


- Geben sie das Datum über die Tastatur ein
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.4**

**Legen Sie nun das Uhrzeitformat fest:**

- Auswahl mit den (▲) / (▼)-Tasten
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.5**

**Stellen Sie die Uhrzeit ein:**

- Die Stunden und Minuten geben Sie über die Tastatur ein
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.6**

**Legen Sie nun das Einheitsystem fest:**

- Auswahl mit den (▲) / (▼)-Tasten
- Bestätigen Sie die Auswahl mit der F3-Taste

**Wenn Custom gewählt wird, müssen die Einheiten für folgende Einstellungen festgelegt werden:**


- Geschwindigkeit
- Temperatur
- Gewicht
- Körpermaße
- Höhen Format
- Verbrauch Format



**1.7**

**Stellen Sie die aktuelle Höhe ein:**


- Eingabe erfolgt über die Tastatur
- Bestätigen Sie die Auswahl mit der F3-Taste



**1.8**

**Es erscheint jetzt die Abfrage, ob Sie mit den Einstellungen fertig sind.**

- Bestätigen Sie mit der F3-Taste




**Diese getroffenen Einstellungen werden nun für die verschieden Bike-Computer übernommen.**

Press the **green button** to switch on the **UFSB**.



You will see:



First, configure the basic settings of the **UFSB** (start settings). Press F3 to go to the General Set.

Press F2 to confirm your selection. The **UFSB** switches to the setting mode for the start settings.

You only need to configure these settings once the first time you use the **UFSB**.

## 1.1

Set the **language**:


- Press the (▲)/(▼) buttons to select your language
- Press F3 to confirm your selection



## 1.2

Now specify the **date format**:


- Make a selection by pressing the (▲)/(▼) buttons
- Press F3 to confirm your selection



## 1.3

Set the **date**:


- Use the keyboard to enter the date
- Press F3 to continue



## 1.4

Now specify the **clock format**:


- Make a selection by pressing the (▲)/(▼) buttons
- Press F3 to confirm your selection



## 1.5

Set the **time**:

- Use the keyboard to enter the hours and minutes
- Press F3 to confirm your selection




## 1.6

Choose your **unit system**:

- Press the (▲)/(▼) buttons to select your system
- Press F3 to confirm your selection

If the **Unit custom** is chosen, the **Measurement unit** has to be defined for the following:

- Speed
- Temperature
- Weight
- Body size
- Altitude
- Fuel format



## 1.7

Set the **current altitude**:


- Enter the information using the keyboard
- Press F3 to confirm your selection



## 1.8

A query now appears asking if you have finished configuring the settings.

- Press F3 to confirm



Once you have fully configured the start settings, these are used as the settings for the various computer models

## FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

Caution: If any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The RF Exposure Compliance distance is 5 millimeters.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## INDUSTRY CANADA STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance 5 millimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 5 millimètres entre le radiateur et votre corps.

## Technical Information

Battery Type	9.0Vdc size "6F22" battery
Operation temperature	0 °C - 50 °C

## EU-KONFORMITÄTSERLÄRUNG

Wir, SIGMA-ELEKTRO GmbH, erklären das die UNIVERSAL FAST SETTING BOX bei bestimmungsgemäßer Anwendung den grundlegenden Anforderungen gemäß EMV Richtlinie 2014/30/EU, RoHS Richtlinie 2011/65/EU und Richtlinie (EU) 2015/883 mit Anhang II der oben genannten Richtlinie mit 4 weiteren Substanzen entspricht. Sie finden die vollständige Konformitäts-Erklärung unter folgendem Link: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

## EU-DECLARATION OF CONFORMITY

We, SIGMA-ELEKTRO GmbH, declare under our responsibility that the product UNIVERSAL FAST SETTING BOX are compliant with the essential requirements and other relevant requirements of the EMC Directive 2014/30/EU and the ROHS Directive 2011/65/EU and additional according to Directive (EU) 2015/883 to amend Annex II of the above mention Directive with 4 additional substances. The declaration of conformity can be found at: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

## CE INFORMATION

**FR** Vous trouverez la déclaration CE à l'adresse : [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

**IT** La dichiarazione CE è disponibile all'indirizzo: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

**ES** Puede encontrar la declaración de conformidad CE en: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

**PT** Poderá encontrar a declaração CE em: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

**NL** U kunt de CE-certificering vinden op: [ce.sigmasport.com/ufsb](http://ce.sigmasport.com/ufsb)

## UKCA STATEMENT

We, SIGMA-ELEKTRO GmbH, declare that the equipment above has been tested in our facility and found compliance with the requirement limits of applicable standards, in accordance with the Radio Equipment Regulations 2017 and the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012. The test record, data evaluation and Equipment Under Test (EUT) configurations represented herein are true and accurate under the standards herein specified.



**SIGMA-ELEKTRO GmbH**  
Dr.-Julius-Leber-Straße 15  
D-67433 Neustadt/Weinstraße